

Y26 Sinker Drill

			2003
Code	Part No.	Description	List
0	Y26	SINKER DRILL	1195.00
1	Y26-303	WATER SWIVEL PIPE	15.55
2	Y26-302	WATER SWIVEL NUT	12.50
2	Y26-302F	WATER SWIVEL NUT (DRY)	12.50
3	GB3452.1-82	O-RING	2.00
4	Y26-301	BACK HEAD	195.00
5	7655-304	WATER TUBE BUSH.	1.35
6	Y26-304	AIR OR WATER TUBE	4.95
7	7655-101	RATCHET RING	36.95
8	8X3-23	PLUG	?
9	Y26-101	VALVE COVER	60.75
10	Y26-102	VALVE CHEST	60.75
11	Y26-103	VALVE	66.15
12	Y26-104	VALVE PLUG	60.75
13	Y26-107	RIFLE BAR	59.00
14	Y26-105	AIR BLOW VALVE	35.80
15	7655-111	RIFLE NUT	29.85
16	Y26-108	PISTON	79.00
17	Y26-109	CYLINDER	295.00
18	Y26-110	CYLINDER SLEEVE	82.50
19	Y26-201	FRONT HEAD	172.00
20	Y26-202	CHUCK	72.25
21	Y26-203	CHUCK INSERT 7/8"	44.50
21	Y26-203A	CHUCK INSERT 1"	44.50
22	YT 25-3.17A	FASTENING PIN	3.25
23	GB 93-87	LOCK WASHER	1.65
24	GB 6172-86	THROTTLE HANDLE NUT	1.65
25	YT 25-3.20	SPRING	1.45
26	YT 25-3.21	DOWEL PIN	1.75
27	12 X 3-23	PLUG	1.85
28	GB 848-85	LOCK WASHER	1.65
29	YT 25-1.14	PAWL	3.25
30	YT 25-1.15	PAWL SPRING	1.35
31	7655-203 A	DRILL RETAINER BOLT	15.20
32	Y26-204	STEEL PULLER	45.55
33	7655-205	DRILL RETAINER SPRING	6.10
34	GB 889-86	STEEL RET NUT	3.75
36	GB 56-88	SIDE ROD NUT	6.25
37	YGP 28-304	SIDE BOLT	18.00
38	Y26-112	OIL PLUG	2.70
39	#:1	HOOP #1	6.00
40	19-04	CONICAL HOSE NIPPLE	8.10
41	19-01	WING NUT	10.15
42	19-16	NIPPLE	10.15
43	Y26-106	SPRING	1.65
44	Y26-308	OPERATING VALVE	32.50
45	YT 25-3.33	RETAINING RING	1.95
46	7655-307	AIR SWIVEL NUT	9.56
47	YT 25-3.12	WASHER	1.69
48	30 X 3-25	O-RING	2.00
49	Y26-307	AIR CONN. TUBE	20.25
50	YT 27-105	DOWEL PIN	2.00
51	Y26-305	RUBBER HANDLE	7.45
52	Y26-306	HANDLE BOLT	22.50
53	GB 889-87	T-HANDLE NUT (M20)	2.25
54	YSP 45-316	OPERATING HANDLE	18.40
55	Y26-111	ON-OFF HANDLE	6.25
56	7655-401	VALVE PAD	0.00
57	GB 119-86	PIN	0.00
58	7655-402	TURNING HANDLE	0.00
59	7655-403	FIXING PAD	0.00
60	7655-404	NUT	0.00
61	7655-405	RUBBER PAD	85.00
62	7655-406	WASHER	0.00
63	7655-407	WATER VALVE	0.00
64	7655-408	RUBBER PAD	0.00
65	13-17	WATER VALVE	7.00